

## ESP 302 Snapshot Update Read Me First

### Installation instructions:

Please check your current snapshot version before running any updates:

1. If the current version is other than 200013, continue as directed by the pop-up menu.
2. If the current version is 200013, make sure to uncheck "Factory reset" box in the pop-up menu as shown in the screenshot below.

Failure to do so will result in controller malfunction and need for repairs at the factory.

### Confirmation

Please confirm you want to **install** the following firmware snapshot:

**snapshot-N200015-ESP302-MREF.tbz**

This operation will take a few minutes, during which the system will be reformatted.

It will not destroy the users' files, which are on a separate partition.

- ☒ Reset the controller's IP address to factory defaults
- ☒ Reset the controller's system/stages configuration to factory defaults
- ☒ Reset all user accounts to factory defaults
- ☐ Factory reset (WARNING: all user files will be destroyed!)
- ☒ YES, I confirm that I want to install this upgrade

**INSTALL NOW**

CANCEL